WELCOME TO BOG™.

WE GOT YOUR BACK.

AND YOUR GUN.

DeathGrip™ Clamp

1. When placing your firearm into the clamp, position it as close to the balance point of the gun as possible. Avoid clamping over accessories that can cause unequal clamp pressure and damage to the clamp pads.
2. Tighten the clamp knob to sufficiently apply clamping force to the firearm.

CAUTION: DO NOT OVER TIGHTEN CLAMP AS THE FOREND CAN BE DAMAGED.

Elevation Tilt

Adjust tension of the elevation tilt using the knob.

Note: This is not a lock. Do not over tighten or leave a firearm unattended.

360° Pan

Adjust tension of panning movement using the knob.

Note: This is not a lock. Do not over tighten or leave a firearm unattended.

Leg Angle Adjustment

1. The leg angle pin can be adjusted to any of the three preset angles:
   - **a.** 20° - Standing Position
   - **b.** 45° - Sitting Position
   - **c.** 85° - Prone Position (This setting also allows for a custom angle between 0°– 85°)

Note: Make sure all legs are fully retracted to their shortest position before using the prone position.

Note: Leg angles cannot be adjusted while locked into position. Move the leg in toward the hub to change the angle pin.

CAUTION: DO NOT FORCE THE ANGLE PIN AS THIS COULD DAMAGE ITS COMPONENTS.

Leg Cam Locks

1. Adjust the length of legs by disengaging the Cam locks and extending each leg to the desired height. Fully engage each cam lock when finished.
2. The adjustment screw keeps tension on the legs so they will not slip during use. Use a 2.5mm hex drive tool to adjust the tension. Open the cam locks prior to making any adjustment (see photo). These screws may loosen due to vibration and must then be tightened slightly in order to make sure the legs do not slip when in use. When adjusting the tension of the cam locks, only turn the screw 1/8 (45°)of a turn at a time. Repeat as necessary to establish the correct—

Leg Cam Locks (continued)

tension. Proper tightening of these screws is enough to hold the weight of the firearm.

CAUTION: OVER TIGHTENING THESE BOLTS MAY CAUSE CAM LOCKS TO BREAK.

Note: Remember to check the tension of the cam locks before each use.

Spiked Foot

1. The Spiked Foot can be adjusted for use on hard or soft terrain. For hard terrain, unscrew the foot so that it fully conceals the metal spike. For soft terrain, screw the foot in so that the metal spike is fully exposed.

CAUTION: THE METAL SPIKES ARE VERY SHARP AND MAY DAMAGE OR SCRATCH CERTAIN SURFACES.

WARNING

1. This product is intended to support the weight of your firearm only, it is not intended to support the direct weight of a person. Applying excessive weight to the tripod could result in slipping or collapse. Either event may result in injury or death due to falls or negligent firearm discharge.
2. Care must be taken to use this product on a stable surface. Falls resulting in injury or death may occur if the product is used in a tree stand, other elevated location, on the edge of a building or cliff.
3. Failure to follow these warnings and instructions may lead to death and/or serious injury and/or damage to property.
4. Never adjust this product with a loaded firearm installed in the tripod, because this could result in a negligent discharge leading to injury or death.
5. Always keep the muzzle of your firearm pointed in a safe direction.
6. Always know your target and what lies beyond in case you miss or the projectile passes through the target.
7. Always keep your finger off the trigger until ready to fire.
8. Ensure firearm is unloaded before clamping or removing the firearm from the tripod.
9. A firearm which is not properly clamped to the rest and held, can recoil and strike the shooter. This can cause injury or death.
10. Failure to properly clamp a firearm to the rest may result in a firearm falling and firing. This can cause injury or death.
11. Never leave a firearm unattended in the tripod.
12. When installing a firearm or crossbow, do not clamp any reciprocating parts, the trigger area, the barrel/cylinder gap on a revolver, or the ejection port. Blocking moving parts, the trigger area, barrel/cylinder gap on a revolver, or the ejection port may result in firearm damage, product damage, or injury.
13. If this product is used with a crossbow, confirm that your fingers are clear of the bow string path before discharge, as impact by the bow string will cause injury.
14. Failure to properly clamp a firearm to the rest may result in a firearm falling and becoming damaged.

NEED TO TALK?

If you have a problem with this product DO NOT return it to the store where you purchased it. **Contact us We're here for you**, but only **M-F 8-5PM**ct.

We like to hunt, too.

CUSTOMER SERVICE:

1-877-509-9160 or

Fill out the contact form at *BTbrands.com/*

AMERICAN OUTDOOR BRANDS CORPORATION™

1800 North Route Z

Columbia, MO 65202

www.aob.com

DEATHGRIP™

PRECISION TRIPOD

BOG™

© Copyright 2018 American Outdoor Brands Corporation.
All rights reserved. #1100501 REV. A

Visit **BOGGEAR**.com

www.

Share your obsession #**BOG**HUNT

ENGINEERED FOR THE UNKNOWN™